PHILLIP JEFFRIES

NATURAL | TEXTURED | SPECIALTY | WALLCOVERINGS

HANGING INSTRUCTIONS

VINYL MALDIVES WEAVES WALLCOVERINGS

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

The look of woven tribal baskets now available in VINYL - merging luxe design with the durability and technology offered by today's performance wallcoverings.

PREPARATION:

Before you cut and hang, please be sure you have:

- 1. The correct wallcovering and the correct amount of wallcovering to finish the job.
- 2. Inspect the wallcovering carefully to ensure it is free of defects:
 - If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries is notified. NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL. All claims must be made within 30 days of the invoice date. No labor claims will be allowed at any time.

BUILDING & MATERIAL CONDITIONS: The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation. All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT PHILLIP JEFFRIES BEFORE PROCEEDING.

WALL PREPARATION:

- 1. The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
- 2. Phillip Jeffries recommends that installers use a hard, acrylic, pigmented, wall-protecting primer that is SPECIFICALLY made for WALLCOVERING INSTALLATION and WALL PROTECTION.

DO NOT USE R-35.

3. Allow the primer to dry thoroughly before hanging.

PHILLIP JEFFRIES

NATURAL | TEXTURED | SPECIALTY | WALLCOVERINGS

HANGING INSTRUCTIONS

VINYL MALDIVES WEAVES WALLCOVERINGS

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

- 1. We recommend a premium, full strength, clear, pre-mixed vinyl adhesive that is heavy duty, strippable and mildew resistant.
- 2. Apply the paste to the back of the paper using a pasting machine, or for hand application a short napped paint roller. Pay particular attention to run over edges so they are sure to be pasted.

TRIMMING

 Since edges are untrimmed, this will require cutting a precision edge on your work table or by making a double cut on the wall.
Diagram A)

MATCH

- 1. 12.6" (32 cm.) Vertical Repeat
- 2. 13.5" (34.29 cm.) Horizontal Repeat
- We recommend a straight match. Once a precision edge is cut, seams should be butted together to create a straight match. (See Diagram A)



TIPS

- 1. Each alternate strip can be reverse hung. After three (3) strips are hung, carefully inspect the wallcovering. If the effect is not acceptable, re-hang the second strip without reversing.
- 2. Apply material above doors and windows as it comes off the roll, DO NOT SKIP.
- 3. A heat gun may be used to allow the vinyl to conform to irregular corners.
- 4. Remove excess adhesive and dirt from wallcovering surface and seams immediately, using a sponge or damp cloth frequently rinsed in clean, warm water.
- 5. Vinyl wallcoverings should be washed regularly to prevent dirt and grime from accumulating. Depending on traffic (light, medium, heavy), vinyl should be washed two or three times a year.
- 6. Ordinary dirt can be removed with mild soap and warm water. A bristle brush can be used to remove dirt from the crevices of deeply textured patterns. Dry wallcovering with a soft, lint-free cloth or towel. For more difficult stains that are only surface deep, the use of a stronger detergent is recommended. WE RECOMMEND ALL CLEANERS BE TESTED IN AN INCONSPICUOUS AREA TO INSURE COMPATIBILITY WITH THE WALLCOVERING.